


DRM300 – IP00	+	LCD DISPLAY	=	RDM300 – IP00
ZN DRM312 40400P00	+	ZC00DISPLAYRDM00	=	ZARDM31240400P00



It's possible to change from SLAVE model (DRM300) to MASTER & SLAVE model (RDM300), only connecting the LCD-Display on the connector.

In this way the regulator became a standalone automatic control, with N° 14 different regulation software, with pre-charged parameters, selectable with the push-buttons.

After the parameters changing, memorize the new values (through the dip-switch) and remove the display